




XIAOMI-MI.COM



Device Management

Long press: Sound Control

Incoming calls: Short press response Holding down reject / reset




The volume of sound at smartphones with the Android system is determined by the manufacturers of smartphones, carefully read the instructions of your smartphone


Manages smartphones with the Android and iOS (STIA international standard interface)


Apple: iPhone 4 / iPhone 4s / iPhone5 / iPhone5s / iPhone6 / iPhone6 Plus Samsung: Galaxy S4 / Galaxy Note 3
Xiaomi: Mi 2 / Mi 2S / Mi 3 / Mi 4 / Redmi 2A / Redmi Note / Mi Note and other new version of smart phones based on Android.

Notice

1MORE headphones does not have the function of storing folded; For headphones we used a reliable and robust steel titanium alloy, which prevents headphones of breaking, so you will be able to for a long time to use headphones, but do not let them over-twisting, to prevent deformation.







Warranty

- 1. Within 7 days of purchase, in case of problems with the functioning of the device, you can choose a free replacement product, return or repair. If exchange or return the goods, you must provide intact packaging unit.
- 2. Within 15 days of purchase, in case of problems with the functioning of the device, you can choose a free replacement or repair of the goods. If exchange or return the goods, you must provide intact packaging unit.
- 3. In the course of one month from the date of purchase, in case of problems with the functioning of the device, you can choose a free repair. If exchange or return the goods, you must provide intact packaging unit.
- 4. Within 3 months of purchase, in case of problems with the operation of the device and must be repaired, the consumer pays the transport
- 5. During the validity period of warranty, the consumer must have and maintain in good form «device», «receipt» and «Warranty Certificate» (three things without which it is impossible to guarantee a service).

Attention!

- 1) failure to provide initial setup instructions and the installation and use of the device:
- 2) problems caused by unauthorized maintenance in service centers;
- 3) damage caused under force majeure circumstances;
- 4) damage arising from the use of an aggresive cleaning solvent, if the device was a long time on direct sunlight or in a cold room (20C - + 50C); problems arising from getting wet or drop the device;
- 5) lack of warranty card or receipt.

List of Faults

Name	List of faults
1MORE Headphones	Improper operation functions described in the manual
	The lack of sound speakers
	The lack of sound microphone
	Improper operation buttons
	Cracks / breakages due to material or construction unit

Note: if arbitrary return the goods within 7 days, you must return the device together with its packaging, and all components in good form and with no damage or breakages, (all components listed in the instructions).

Accessories

Manual



Headphones



Cable



Pouch for storage



Sign up for www.1more.com, here you will find a lot of interestina! Please note, you have a chance to win Mi Phone and other prizes!

Producer: «Appliances and Electronics»

Address: Shenzhen, Nanshan district, building XiLiTianLiao