

Using the remote control

Accessories

Remote control
Batteries x2
Remote control strap

Settings


1. First, insert 2 batteries (type 7)

Open the back cover for the battery, insert 2 batteries (type 7) and close the flip cover.

2. Connection

The main TV menu sign in Mi TV devices> External and Bluetooth> Mi Bluetooth Control Panel> Add Mi remote control, follow the instructions of the TV. After a successful connection, the TV will be notified of the successful pairing of devices.

Use the remote control



Using the remote control strap

1. Pull the strap loop through the hole at the bottom of the battery compartment;
2. Once you pulled loop strap through the hole at the bottom of the battery compartment, slide it through the latch between the two batteries;
3. Insert the batteries, and close the back cover of the battery compartment.

Notice

1. Mi remote control may be connected to all kinds of Mi TV 2, including 40-inch, 49-inch, 55-inch Mi TV 2 and the 48-inch Mi TV 2S.
2. To ensure the normal operation of the remote, upgrade the TV system version to 1.1.82 and above.

Home: quick access of home page.

Menu: demonstration of interface and various functions. The interface online video: go to the search; interface file playback recorded video settings; You can also find more video categories in interface listings, etc.

Options wheel: control choice (up, down, left, right). While watching the video using these buttons, you can rewind the video fast forward, backward ..

Set: You may use it as Pause/Start button while watching a video.

Back: One step back.

Warranty

Warranty service maintenance is carried out according to the law on «The rights of consumers» and «Law on product quality.» In warranty service includes:

During the warranty period you can repair, modify or return the product. For repair, replacement or return of goods, you must present the receipt.

1. Within 7 days of purchase, in case of problems with the «List of faults» service center Xiaomi determine the cause of the problem, then you can choose a free replacement product, return or repair.

2. Within 8-15 days from the date of purchase, in case of problems with the «List of faults» service center Xiaomi defines the problem, then you choose a free replacement or repair of the goods.

3. During the 12 months of purchase, if there is a problem with the «fault list» service center Xiaomi defines the problem, then you have free repair.

4. Damage to structures due to the human factor at the end of the guarantee. For example: mechanical damage of housing or buttons of the device; In this case no warranty provided.

XIAOMI-MI.COM