Mi Mouse

User manual

Thank you for choosing our products. This product is a portable computer mouse designed for the mobile lifestyle. The mouse has two connection modes via Bluetooth or radio at a frequency of 2.4 GHz. Excellent performance of this device make it possible to adapt to different conditions of use.

A: Connection Mode on the 2.4 GHz radio



* Method of controlling of this mouse is similar to regular mouse

* At the first connection, default connection mode is by radio.

B: Connection mode via Bluetooth

1. Turn on the Bluetooth function on the computer

2. Hold down the «connection mode» button, until indicator light turns on.



* In order to use the product in Mac OS, it is necessary that the Bluetooth chip version was BCM20702 and above, as well as the operating system must be version 10.10 or later.

3. On your computer find this Bluetooth device (Device Name: MiMouse)



* When using the connection mode via Bluetooth, connection of the USB adapter to the computer is not required.

4. Press «Connect» for accomplishment of connection of the device. After successful connection, the mouse can be used for designated purpose in the Bluetooth mode.





* Long pressing of the «Connection Mode» button allows to connect the device repeatedly.

* Short clicking of the «Connection Mode» button executes switching between the connection modes on a radio communication or via Bluetooth.

Main parameters:

COMA

Product name: Portable mouse of Xiaomi CMIIT ID: 2016DP4530; Product model: XMSB01MW; Connection method: Bluetooth 4.0 and radio communication of 2.4 GHz; Operating system: Windows 7 * / 8/10 (Windows 7 is completely compatible in case of connection through Bluetooth) Sensor type: Laser; Period of operation: of 1 year, under normal conditions operation; The used materials: ABS plastic + aluminum alloy; Weight: 77,5 gr Maximum distance of detection: 10 m Working temperature: 10 °C + 50 °C Input parameters: 3B = 3 mA Power consumption: 10 mW (in working order) 260mkvt (in a standby mode in case of connection through 2,4G) 300mkvt (in a standby mode in case of connection through Bluetooth) 120mkvt (in the sleep mode)

Name and content of harmful substances:

Detail name	Harmful substances					
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Mouse components	>°	0	0 BLOBAL	0	0	9
Metal case	ТҮ О	0	0	0	COOIMUN	O YE
Adapter	0	0	0	0	0	0
Packing box GLOBAI	0	0	0	0	GLOBA	0

This table is made according to the SJ standard / T 11364.

•: Means that the content of the given substance in the corresponding part of a product doesn't exceed admissible value according to requirements of the GB standard / T 26572;

×: Means that the content of the given substance in the corresponding part of a product exceeds admissible value according to requirements of the GB standard / T 26572.

Caution:

In case of hit on imprudence of any liquid in a product, it is necessary to turn off connection to the computer at once. Further use of a product can lead to ignition or blow by current. Please contact in this case representative office or the nearest customer service center.

Don't allow hit of a beam of the laser in eyes at all.

Do not use the mouse near a heat source or open flame.

Except the ways of use of a product specified in this instruction please don't try to sort or replace any details in him.

Warranty service of Xiaomi portable mouse

Warranty terms and conditions:

Service of Xiaomi portable mouse, namely: return, repair or exchange, are carried out strictly according to «The law on consumer protection» and «The law on quality of production». Service is included:

In case of detection of one of the breakages specified in «the list of possible functional malfunctions» within 7 days from the date of a list about receiving goods, and receiving confirmation from the center of service after-sales service of the Xiaomi company, it is possible to use free of charge service of return or replacement of goods.

In case of detection of one of the breakdowns specified in «the list of possible functional defects» within 8-15 days from the date of a list about goods receipt, and receipts of confirmation from the center of field after-sale service of the Xiaomi company, it is possible to use free of charge service of replacement or repair of a product.

In case of detection of one of the breakdowns specified in «the list of possible functional defects» within 12 months from the date of a list about goods receipt, and receipts of confirmation from the center of field after-sale service of the Xiaomi company, it is possible to use repair service free of charge.

Useful recommendation:

Due to the need of using a packing box for safety of goods in the course of transportation, we recommend to you to keep a packing box within 15 days from the moment of the signature about receiving goods.

The conditions under which offers warranty repair service:

Unauthorized repair, misuse, mechanical damages, hits of liquid, damage on imprudence, unauthorized change, use of components, incompatible with this product, and also removal, change of the label and marking, excludes unauthorized opening;

The termination of all terms during which provision of warranty maintenance stated above is possible;

Damage of goods owing to force majeur circumstances;

Emergence of the malfunctions connected with operation of this device and its components specified in «the list of possible functional malfunctions» owing to human influence.

GLOBAL

XIAOMI-MI.COM