

User's Manual

#### Accessories

- 1. Tracker;
- 2. Charger;
- 3. Manual;
- 4. Warranty Certificate.




Tracker body + removable strap + charger

Download the app after completing registration, press the search button and link tracker with a smartphone.



## Automatic start of charging

If you touch the button and the bracelet screen does not glow, first charge the device, and then return it to your hand. Connect the charger to the bracelet in the direction shown, connect it to a source of electrical current. A charging status indicator appears on the screen, the tracker automatically turns on. While charging, watch the charging port to avoid contamination of contacts, water ingress, or other hazards.



Download and install the application on your phone.



Scan the QR code for download and install the Hey + program, or find the program in the Playmarket.

### Access to Mi Home

«Works with MiJia» means that the product can support the Mi Home application or Xiaoai home devices. Please note that the bracelet was connected to the Mi family only for checking the software level, Xiaomi and MiJia do not do this by default.





Scan the QR code and install the Mi Home app.





#### Parameters

Item Name: Hey+ Tracker;

Model: B1800;

Screen: AMOLED display; Main body weight: 19.7 g


Bracelet material: plastic elastomer; Fastener material: aluminum alloy; Adjustable length; 155 mm, 205 mm; Water resistance level: 50 meters; Temperature range: 0 ° C - 45 ° C; Wireless connection: Bluetooth 4.2:

Input voltage: DC 5V; Input current: 90 mA; Battery capacity: 120 mAh; Battery type: polymer;

To use the bracelet, you need devices that

support Android 4.4 + / i0S 8.0.

### Using



After linking the tracker, it can be controlled using the touch screen.

Swipe down to access the notification panel. Slide your finger up to enter the menu bar.

Swipe up and down to drag the screen to scroll and click to enter the corresponding function.

Press the touch button to return to the previous screen.

#### ng

### The functions, given in the manual, are inoperative;

List of Faults

- The screen does not glow, does not work;
- No vibration;
- Cannot synchronize with the specified device;
- Damage to the hull due to structural or material factors;
- No power in cable or device contacts;

# Warranty

- 1. Within 7 days from the date of purchase, in case of a problem with the "List of Faults", the manufacturer's service center determines the cause of the problem, after which you can choose a free product replacement, refund or repair.
- 2. Within 8–15 days from the date of purchase, in case of a problem with the "List of Faults", the service center determines the problem, after which you choose a free replacement for the product or service.
- 3. Within 12 months from the date of purchase, in case of a problem with the "List of Faults", the service center determines the problem, after which you are provided with free repair.

### Presence of toxic and harmful substances

Name	Toxic and hazardous items and materials.					
	Pb	Hg	Cd	Cr	PBBs	PBDEs
Tracker	х	0	0	0	0	0
Battery	0	0	0	0	0	0
Bracelet	0	0	0	0	0	0
Fastener	0	0	0	0	0	0
USB cabel	Х	0	0	0	0	0